This document illustrates the features included in Essentials and Advanced for the NetCloud Solution Packages.

IoT

From setting a 114 co	Essentials	Essentials +
Functionality	(Standard)	Advanced (Prime)
WAN		
Connection Manager	√	√
LTE	√	√
WiFi-as-WAN	√	√
Wireless Client ⁺	√	✓ ✓
Smart WAN Selection	✓ ✓	∨ ✓
QoS		∨ ✓
Traffic Steering	V	V
Enterprise Routing		
Static Routes	✓	✓
Policy Routes*	✓	✓
OSPF *		√
BGP *		√
RIP *		√
VRRP *		√
STP		√
NHRP *		√
NEMO / DMNR Primary		√
NEMO / DMNR Failover		√
Linked Router Management (LLDP)		<u> </u>
DMVPN / NHRP*		V
VPN & Tunneling		
IPSec	√	√
GRE	√	√
OpenVPN (SSL VPN) *		√
L2TP *		√
AutoVPN		√
Security		
Zone Firewall	✓	✓
Application Aware Firewall		
Application Aware QoS Pagin URL filtering (Milita/Plage light)	√	√
Basic URL filtering (White/Black list)	V ✓	V ✓
Threat Intelligence Web Reputation	→	,
	→	,
Activity Audit Log	·	·
NetCloud Perimeter	,	•
CP Secure Web Filter		
CP Secure Threat Management (IPS/IDS optional package)	√	√
Zscaler Internet Security (optional package)*	√	V
LAN		
IPv4 & IPv6	√	✓
DHCP Server	✓	✓
DHCP Relay	✓	√
1024 VLANs	✓	✓
VRRP*		✓
WiFi		,
Multiple SSIDs	√	√
WEP	√	√
WPA / WPA2 Personal	√	√
WPA / WPA2 Enterprise	√	√
Smart Channel Selection	√	√
HotSpot Services*	✓	✓
Remote Connect / Out-of-Band Management		
Securely connect to device UI in any network architecture		✓
Securely connect to device CLI in any network architecture		·
Out-of-Band Management for Access to non-Cradlepoint devices with console port		·
LAN Manager for Access to LAN connected 3rd Party Device UIs		·
J		
Secure Remote Cloud Configuration		
Individual Device Configuration	✓	√
View / Edit Device Configuration	√	√
Clear Device Configuration	√	√
Remote Reboot	√	✓

Restore to Factory Defaults	√	✓
Export Device List	√	·
Group Device Configuration	√	√
View / Edit Group Configuration	√	√
Export Group Device List	√	√
Group NetCloud OS Updates	√	✓
Copy Configuration to Group	√	√
WAN Network Interface Configuration	√	√
View/Edit Network Interface Configuration	✓	√
Export Network Interface List	✓	✓
Modem Configuration	√	√
Modem Firmware Visibility & Management	✓	✓
Modem Firmware Updates	✓	✓
Auto & Manual Modem Carrier Switching *	✓	√
Scheduler	✓	✓
NetCloud OS Updates	✓	√
Real-Time Diagnostics / Troubleshooting		,
Basic Real-Time Device Status	✓	√
Advanced Real-Time Device Status		√
Basic Network Interface Status	✓	√
Advanced Network Interface Status		√
Ping	√	√
Traceroute	✓	√
Speed Test per WAN Interface	✓	√
Device Log	✓	√
Debug Diagnostic Data Log	✓	√
User Activity Log	✓	✓
Rogue AP Detection	✓	√
WiFi Site Survey	✓	√
Visibility / Analytics		
Network Dashboard	✓	✓
Group Dashboard	√	✓
Device Dashboard	✓	✓
LAN Client Dashboard		✓
WAN Data Usage	√	
Modem / Carrier (Pooled) Data Usage Analytics		
WAN Uptime Analytics		√
Application Traffic Analytics		·
GeoView Location Services**		
Device Map Location with quick view status**		√
Geo-Fence Alerting for physical security**		✓
Alerts / Reports		
Alert Management	✓	√
Network, Group, Device Reporting	· ✓	
Activity Audit Log	· ✓	
. s		·
Extensibility		
Custom busines applications running at the edge with NCOS SDK	✓	✓
NetCloud API	√	√
Accounts & Hoors		
Accounts & Users Manage Users	√	√
Manage Users Manage Permissions	∨ ✓	✓
	∨ ✓	✓
Active Directory Domain Authentication (Federated ID) Single Sign On (SSO) to all Cradlepoint Services	∨ ✓	✓
omigre orgin on (000) to an Gradiepoint bervices	v	Y
* Not available on IBR2x0		

** Not available on IBR6x0B

† Only available on the IBR600C